

HOW TO CUSTOMIZE HOSE LENGTH

- Step 1* > Measure and mark desired length of hose.
- Step 2* > Secure sock in place to prevent the sock from shrinking up onto the hose when the excess hose is cut off.
- Step 3* > Remove end cap.
- Step 4* > With sharp scissors, cut off excess hose and sock, leaving 2.5 cm (1") excess sock to tuck into end of hose. This needs to be a clean cut.
- Step 5* > Tuck sock into end of hose.



- Step 6* > Re-install end cap all the way into the hose, being sure sock is secured around entire circumference of end cap. When looking into hose through the end cap, no sock should be visible inside the hose. If sock is visible, remove the end cap, adjust, re-install end cap.

